

WINE CABINETS

Tastvin

INSTALLATIONS:

Your wine cellar will have to be put in a dry, well-ventilated. Any source of heat will have to be removed not to modify the perfect environment of

temperature you may have found. The ground on which your wine cellar will be set, needs to be stable and level. The temperature should be maintained at reasonable levels: not exceeding 30°C, and not lower than 0°C.

The cellar can be levelled very easily with the help of the base. <plug and play>! But not forget to plug it in allowing a delay of two days. The cellar is supplied with electrical power; the plug needs to be easily reached.



HOW TO POSITION YOUR UNITS:

Units can be stored individually on each sliding shelf or they can be stacked up. **Individual storage:** pull the shelf till it stops then you can store up to 11 units starting at the back.

If you want to stock temp up: lock in the shelf then stack up the units, max. 4 levels.

HOW TO CLEAN THE WINE CELLAR:

Never use corrosive products or products containing ammonia for the inside. Use a classical dust removal product for the outside. once a year you should dust off the rail back of the cellar.

ARMOIRES A VIN

Tastvin



INSTALLATION:

L'emplacement de votre cave à vin devra être dans un local suffisamment aéré, pas trop humide, éloigné d'une source de chaleur et sur un sol stable et plan.

La température du local entre 0 et 30°.

Stabiliser l'armoire de niveau en agissant sur les pieds.

Attendre 48h avant de brancher l'appareil.

La fiche de prise de courant doit être accessible lorsque l'armoire est en place.

MISE EN PLACE DES BOUTEILLES:

Chaque étagère est utilisable en rangement individuel coulissant ou en empilage.

Rangement coulissant individuel: tirer la clayette jusqu'à la butée, ranger 11 bouteilles dans les emplacements prévus en commençant par le fond.

Empilage: verrouiller la clayette en position rentrée à l'aide du verrou situé à l'arrière fond gauche de la clayette. Empilage maximum sur 4 hauteurs.

ENTRETIEN:

Les parties intérieures se nettoient avec de l'eau et du savon ou avec un nettoyant pour vitres.

Une fois par an, dépoussiérer la grille à l'arrière de l'appareil.